


Product FAQ


YELLOW FLAME

Q1. Why does yellow flame appear at the burner?

A1.1 You should adjust the air damper in order to turn the yellow flame to be blue flame.



A1.2 Your burner ring or burner cap is dirty or clogged with stains, you can clean it green sponge with some soap water.



Q2. Where is air damper?

A2.1 Air damper is located at the bottom of the Glass Hob



Note: If the matter as mentioned above still exist, please call to Service Centre for further assistance.